



External core temperature probes.

Precise monitoring, perfect results.



Availability for RATIONAL cooking systems

iCombi Pro / iCombi Classic / CombiMaster Plus XS	Energy type	Single externally attachable core temperature probe	Sous-vide core temperature probe
Size XS	Electric	–	–
Combi-Duo XS	Electric	–	–
Size 6-half size, 10-half size	Electric / gas	•	•
Size 6-full size, 10-full size	Electric / gas	•	•
Combi-Duo 6-half size on 6-half size or 6-half size on 10-half size	Electric / gas	•	•
Combi-Duo 6-full size on 6-full size or 6-full size on 10-full size	Electric / gas	•	•
Size 20-half size*	Electric / gas	•	•
Size 20-full size*	Electric / gas	•	•

• Available / – Not available

* Versions for floor models have extended cables to make using them more ergonomic.

Internationally tested



RATIONAL USA
 1701 Golf Road
 Suite C-120, Commerce
 Rolling Meadows, IL 60008
 Tel. 888-320-7274 (Toll Free)
 Fax 847-755-9583
 info@rational-online.us
 rationalusa.com



80.25.222-V-01-MDS/SPS-08/20-en_US
 We reserve the right to make technical changes in the interest of progress.

External core temperature probes.

Precise results, flexibility, and exceptional quality.

The external core temperature probes expand your range of options and allow you to monitor your results even more effectively.

You can use the sous-vide core temperature probe to monitor the system as it reaches the precise temperature you've set, so you'll get perfect results again and again.

① Sous-vide cooking

The special extra-thin sous-vide core temperature probe supports the iCombi's cooking intelligence in achieving the target core temperature precisely, without tearing the vacuum bag when using foam tape.

Delivery includes:

- > USB connection box with 1-point sous-vide core temperature probe
- > Core temperature probe holder
- > Magnetic bracket for USB connection box

② Externally attachable core temperature probe

The core temperature probe has 6 measuring points, and can be used with any cooking process. It can be used in place of the internal core temperature probe.

Delivery includes:

- > USB connection box with one 6-point core temperature probe
- > Core temperature probe holder
- > Magnetic bracket for USB connection box

③ USB port outside the cooking cabinet

The external USB port makes it easy to install additional core temperature probes and use them on different cooking systems. When no core temperature probe is attached, a cap covers the USB port and protects it.

④ Magnetic bracket / Holder for core temperature probe

The USB connection box is attached above the display using a magnetic bracket. When you are not using core temperature probes, you can store and protect them in the holder on the side of the iCombi Pro or iCombi Classic. The holder can be removed for cleaning.

